


1) The connection standards


1.a. The FC28 remote control (Robbe-Futaba)

View of the connector at the rear side of the emettor



1.b. The Multiplex "Europa Sprint" transmitter


View of the connector at the top side of the emettor



1.c. The Graupner adapter


View of the female connector used with Graupner Remote control

Connector type: Jack 3.5mm mono



2) How to connect 2 remote control


How to connect a school remote to a teacher remote



The teacher remote must have the hardware for the school signal treatment, and a switch assigned to the selection of the data to transmit. The FC28 is always released including that hardware. You have to activate that function by software.

Disable the school remote RF circuit (remove the quartz or the complete module), because only the teacher must transmit the radio signal.

How to connect a school remote to a computer simulator



Make your appropriate connection cable according the remote you have.

Put an audio cinch connector pair at the middle of the wire, to prevent damage on the remote connector when the wire are pulled (when walking).